



Merton Group UK Ltd

Cleaning and Hygiene Products That Don't Cost the Earth

TECHNICAL DATA SHEET

DISHWASHER CLEANER DESCALER – 0730

A freeflowing dishwasher powder specially formulated to remove limescale and deposits during the wash cycle.

USES:

A freeflowing dishwasher powder specially formulated to remove limescale and deposits during the wash cycle.

DIRECTIONS:

Use 200 grams on a short cycle with the dishwasher empty.

TECHNICAL SPECIFICATION:

Appearance	Cream powder
Odour	None
pH	ca 1.5
Filling density	ca 1000 - 1100 g/l
Water solubility	High
Stability	Stable under normal conditions. Avoid Alkalis

Safety: Keep out of the reach of children.

Contains Sulphamic Acid. Irritating to eyes and skin. Avoid contact with eyes and skin. Rubber gloves and eye/face protection are recommended.

If swallowed do not induce vomiting. Rinse mouth with water. Drink plenty of water and seek immediate medical attention, showing this label.

In case of contact with eyes rinse with plenty of water and seek medical advice.

After contact with skin, wash immediately with plenty of water.

