



Merton Group UK Ltd

Cleaning and Hygiene Products That Don't Cost the Earth

TECHNICAL DATA SHEET

BIO HAZARD DISPOSAL KIT AND SCOOP - 4108

A convenient single application kit for bodily fluids – blood, vomit and urine.

- ❖ Supplied in a vinyl wallet or polybag
- ❖ Ideal for dealing with individual body fluid incidents

USES:

A convenient kit for dealing with individual body fluid incidents. Ideal for use in doctor's surgeries, schools, nurseries, care and nursing homes etc.

DIRECTIONS:

Put on the apron and gloves.

Sprinkle the powder onto the body fluid (the powder instantly forms a gel and binds liquid and semi liquid for quick and easy removal).

Use the scoop and scraper to put the gel into the bio hazard bag. Use cloths to soak up any excess and put in the bag.

Spray the affected area with the disinfectant spray then dispose of the gloves and apron in the bag and use the disinfectant wipe on your hands.

TECHNICAL SPECIFICATION:

Appearance	White powder
Odour	Lemon
Solubility	Not soluble in water

Avoid wet, humid conditions
Store in a cool, dry area. Keep in sealed containers.

Safety: Keep out of the reach of children.

In case of contact with eyes, rinse for 15 minutes with plenty of water.

If swallowed, wash out the mouth with water. Seek medical advice if necessary.

After contact with skin, wash with soap and water.

If inhaled, remove any material from the mouth and free the air way. Remove the person to fresh air.

